






»SC521+522«
















(EE) *Montaažjuhend*

(GB) *Assembly instructions*






(FI) *Asennusohjeet*



(RU) *Инструкция по монтажу*

<< 521 >>


A	18 x  Ø8 x 35	Ac	4 x  Ø8 x 30	C	6 x 	Ca	6 x 	Db	2 x  M4 x 25	Ea	14 x  Ø3,5 x 15
F	1 x  4 mm	G	6 x  L - 34	Gf	6 x  Ø15 x 14	H	16 x  Ø7 x 50	I	50 x  Ø1,2 x 20	M	2 x  Ø25
Pz	2 x  Ø15 x 27										

<< 522 >>


A	6 x  Ø8 x 35	G	3 x  L - 34	Gf	3 x  Ø15 x 14	H	3 x  Ø7 x 50	N	12 x  Ø5/Ø5
----------	---	----------	--	-----------	--	----------	---	----------	--





<< 521 >>




<< 522 >>






A	24 x	C	6 x	Ea	2 x	G	9 x	M	2 x
Ø8 x 35				Ø3,5 x 15		L - 34		Ø25	




1

Gf 9x
Ø15 x 14








2





F 1x H 15x
4 mm Ø7 x 50




3







5

Ca	6 x	Db	2 x	Ea	12 x	Pz	2 x
							
		M4 x 25		Ø3,5 x 15		Ø15 x 27	



6 x2

Ac	4 x	N	12 x
			
Ø8 x 30		Ø5/Ø5	



7



Tähelepanu • Attention • Увага • Внимание



EE	Uste reguleerimine (hingede reguleerimine)
GB	Adjusting the doors (adjusting the hinges)
DE	Säätäminen ovet (säätäminen saranat)
RU	Регулировка дверей (регулировка шарнира)

