


»SC530«




(EE) *Montaažijuhend*


(FI) *Asennusohjeet*



(GB) *Assembly instructions*

(RU) *Инструкция по монтажу*







A	30 x Ø8 x 35	Ac	4 x Ø8 x 30	C	9 x	Ca	9 x	Db	3 x M4 x 25	Ea	18 x Ø3,5 x 15
F	1 x 4 mm	G	12 x L - 34	Gf	12 x Ø15 x 14	H	22 x Ø7 x 50	I	75 x Ø1,2 x 20	M	2 x Ø25
N	16 x Ø5 / Ø5	Pz	3 x Ø15 x 27								







A	30 x	C	9 x	Ea	2 x	G	12 x	M	2 x
	Ø8 x 35				Ø3,5 x 15		L - 34		Ø25















2






3







7 x3



8



Tähelepanu • Attention • Huomio • Внимание



EE	Uste reguleerimine (hingede reguleerimine)
GB	Adjusting the doors (adjusting the hinges)
FI	Säätäminen ovet (säätäminen saranat)
RU	Регулировка дверей (регулировка шарнира)

